



3221 San Fernando Rd, Los Angeles, CA 90065

Tel: (800) 888-8148 * Fax: (323) 255-1312

Web: www.ninjabump.com E-mail: info@ninjabump.com

OWNER'S MANUAL SAFETY RULES

Double Lane Slide

SKU: NDL-S

READ AND SAVE THESE INSTRUCTIONS



OWNER'S MANUAL OPERATING INSTRUCTIONS & SAFETY RULES

(Ninja Jump's Giant Slide)

Double Lane Slide

Product Dimension:

27'0"L x 19'6"W x 18'0"H – 575 lbs

OPERATING INSTRUCTIONS


Select the area in which the inflatable will be inflated. The following ground locations are good for setting up the jumper: medium dense coarse sands, sandy gravels, very stiff silts, and clays. Select an area which is at least 6' larger than the inflatable's base so you will have a 3' clearance on all sides. Before setting up the inflatable, check and make sure to have at least a 15' clearance from overhead telephone wires, or any other utility wires, etc. Also, check the area for any ground obstructions such as protruding sprinklers, underground pipes, etc. Make certain that you pick a level area to set the inflatable on and not one that's hilly or slanted. Place the unit in the middle of the selected area. Always use the tarp, set the tarp down first and place the jump on it. Untie straps and unroll.



Connect tube (choose the one closest to the electricity source) to the blower. If there is more than one air tube, twist the vent of the other tube/s several times, fold it over, and secure it with a strap. Check all tubes for snugness to make certain that no air is escaping and re-tie and re-connect, if necessary. Also, check the air intake on the side of the motor/blower for blockage. Make sure to always use a 1 hp blower with a minimum of 700 and a maximum of 900 CFM.


When using an extension cord, choose a 50' 12 gauge exterior UL-approved cord to accommodate longer distances to the electricity source. Always plug motor/blower into a 115V outlet 20 amp circuits (usually found in kitchens and laundry rooms) and inflate the unit.

After the unit is inflated, check with the customer if the placement of the inflatable is satisfactory. If so, connect the 3/8" steel shackle found on the tie down straps of the ride to the 330A Chance Anchor and drive the anchor into the ground at a minimum depth of 16" and at a 45° angle on all tie down straps and at all locations as provided by manufacturer on the particular ride. The high-level tie-down straps should be anchored 3-5 feet from ride. Remember to install the soil anchors at such distance from the jumper that the jumper straps connected to the shackle and anchor would be taut.



Note: Please see attachment # 1

If the unit is on cement or any hard surface, to protect the base of the unit from abrasion, make sure that you have put the tarp down and placed the unit on it before inflating it. Use sand bag pouches that can carry a minimum of 30 lb. tension load per anchor point. Connect the tie down straps to the sand bag pouches. Remember to install sand bags at such distance from the ride that the ride straps connected to the shackle would be taut.



BLOWER INSTRUCTIONS

1. Applications:

The primary application for the blower is the pressurization of inflatable interactive games and other types of inflatables requiring sustained high air pressure.

2. Operation:

Place the blower in the desired area pointing towards the inflatable. Place the blower on a stable surface. Attach the inflation tube around the exhaust opening by means of a strap. Cinch the strap tightly, being sure that it has gripped the blower behind the raised portion of the exhaust, to assure the inflation tube is correctly and solidly attached. Plug the cord into a grounded outlet or extension cord that has been grounded through a GFCI. Turn on the singly speed switch.

3. Safety Information:

- 3.1. Do not use in standing water. Even though the blower may be described as weather resistant, do not run blower when there is a chance of getting motor and wiring wet or damp.
- 3.2. If blower gets wet, and water is inside blower, tip the blower to drain water out of the drain holes. Once water is drained, allow blower to dry thoroughly before resuming operation.
- 3.3. Keep children away from blower while plugged in and / or in operation.
- 3.4. Ensure that the power source is sufficient for the power requirements of the blower.
- 3.5. Do not look into the discharge outlet of the blower. Foreign objects may become dangerous projectiles.
- 3.6. This blower is to be operated only with the proper safety guards in place to prevent persons and objects from contacting the revolving blower wheel. Any other use voids the warranty and creates unsafe conditions.
- 3.7. Do not insert foreign objects or body parts into the blower. Do not block, move, or tamper with the blower in any manner while it is in operation.
- 3.8. This blower must have backpressure to operate properly. In other words, an inflatable must be attached to the blower prior to turning on the blower.
- 3.9. Do not position this blower where it can blow dust, dirt, or other objects at people in the airflow pattern.
- 3.10. This blower is intended for inflating (pressurizing) inflatable objects. Operating the blower for other than this prescribed use will void warranties and can cause other unsafe conditions.
- 3.11. Do not use the blower in potentially dangerous locations such as inflammable, explosive, chemical laden environments.
- 3.12. To avoid possibilities of damage to blower or problems with operation, place the blower on a smooth and level surface.

- 3.13. Never operate the blower without safety guards in place. If guards are removed for servicing, then they must be replaced to the proper position before operation of the blower.
- 3.14. Inspect the unit carefully before each use. If the unit appears to have damage, repair or replace before use.

WARNING: When restarting the fan following a power outage, be sure that the inflatable does not cause the fan to spin backwards. The blower will not properly inflate the ride if the fan is spinning backwards.

4. Electrical Safety:

- 4.1. Ensure that the power supply exceeds the requirements of the blower for safe operation.
- 4.2. The power cord is equipped with a three-prong plug that must be inserted into a matching receptacle. Do not remove or cut off the ground prong off the plug.

WARNING: Use of a three prong to two prong adapter is not recommended. Improper connection may create the risk of electrocution.

5. Extension Cords:

- 5.1. Use the shortest possible length. When extension cords are used, ensure that they are UL listed for outdoor use and of the proper gauge and length. Cords up to 50 ft. in length should be no smaller than 14-3. Cords that are up to 100 ft. in length should be no smaller than 12-3.
- 5.2. Do not kink cords or allow contact of oil, grease, moisture, chemicals, hot surfaces, or sharp and abrasive objects. Replace worn or damaged cords.
- 5.3. Unplug the power cord before cleaning or servicing.

WARNING: Do not depend on any switch or other controlling device as the only means of disconnecting power when installing or servicing the blower. Always unplug the power cord. Failure to do so may result in electric shock. This could be fatal.

6. Trouble-Shooting Chart:

<u>Problem</u>	<u>Possible Causes</u>	<u>Corrective Action</u>
Blower does not run.	Bad power supply.	Check cord or power outlet Check GFCI, if using one Is circuit breaker tripped?
	Broken/faulty cord	Replace cord
	Defective motor/switch	Replace motor or switch
Fan runs slow	Too small power cord	Use 10-3 or 12-3 cord
		Clean inlets

<u>Problem</u>	<u>Possible Causes</u>	<u>Corrective Action</u>
Poor air flow Fan blows circuit breaker	Restriction on air inlets Too long extension cord Other appliances in outlet	Clean inlets Max. length is 100 ft. Move closer to outlet Find cleaner circuit or Different higher rated breaker
Scraping noise in blower Noise fan, weak pressure	Blower wheel imbalanced Fan spinning backwards	Replace blower wheel Switch off fan, grab air duct To prevent backflow and Switch on again after fan stops completely.

SAFETY FIRST

A Warning Sign with the following copy is attached and made part of each inflatable. All rules should be followed for rider's safety.

- SUPERVISION by a qualified attendant is required at all times
- The ride MUST be securely tied down. (See operating instructions)
- The blower requires a GROUND fault protected circuit (GFCI).
- DO NOT use and immediately deflate the ride, if winds exceed 15 MPH (25 KPH) and / or when it rains.
- Individuals who may be particularly susceptible to injury from falls, bumps, or bouncing should not use this product. You should consult a physician before using this product
- REMOVE shoes, eyeglasses and any sharp objects.
- NO food, drinks, gum, pets or silly string
- Somersaults, diving, wrestling, rough play and flips are prohibited.
- Play at a safe distance from others and away from the sides and entrances / exits.
- DO NOT jump onto or off the ride
- EXIT immediately if the unit begins to lose air.
- Go down the slide FEET FIRST ONLY, one rider at a time for each lane.
- NO CLIMBING up the slide the wrong way, NOR JUMPING onto the slide area.

ADDITIONAL SAFETY RULES

1. No riders should be allowed on a partially inflated unit.
2. All Inflatables should be securely anchored and fully inflated before any riders are allowed to enter.
3. Maximum number of riders of each group that should play in the unit at one time is 2 riders or a Maximum Weight of 500 lbs; Rider height requirements: Minimum Height – 42”; Maximum Height – 72”
4. Under no circumstances is climbing on the exterior of the inflatable allowed.
5. Adult supervision is required at all times while the inflatable is in use. Minimum required operator/attendant: one (1).
6. The blanket should be used on all sides at all times.
7. Do not install inflatables near a pool.
8. Caution should be exercised when lifting and handling the equipment.
9. All extension cords and straps should be placed in such a manner that no one can trip on them. Also, no electrical cords should run through puddles or near a pool.
10. Never remove the ground pin from the cord. Use an adapter.

EMERGENCY EVACUATION PROCEDURE

The Attendant, before operating the ride, must familiarize himself with the ride’s entrance/exit as well as escape hatches. In the unforeseeable event that power is interrupted and the ride begins to lose air, the Attendant should guide all the riders to calmly and orderly leave the ride via the entrance/exit.

All rides that have permanent roofs feature Escape Hatches on the roof. The Attendant may choose to have the riders exit the ride through these easily accessible escape hatches. All rides, such as The Challenge, that do not have roofs offer the Attendant the alternative of allowing the riders to exit the ride through the wide openings around the unit.

If the Attendant determines the weather conditions warrant closing down the ride or in the event of a power failure, the following procedure shall be observed:

1. Stop riders from entering the device, including parents.
2. Riders in the bouncer shall be told to leave through the entrance in an orderly manner, as rushing may intimidate smaller and more timid riders.
3. Riders on the lower section of the climb shall be advised to climb back down and exit through the obstacles portion.
4. Riders on the upper part of the climb and the slide itself shall be instructed to proceed to the slide and exit the normal way. Apply the normal slide rules of one person on the slide at a time.
5. It takes close to two minutes before the slide starts to sag noticeably and, even then, a rider may safely slide down and exit. Evacuation time is 30-45 seconds.

REPAIRS & MAINTENANCE

To repair holes and tears up to 12", use "Single Patch Method," utilizing the patch kit provided with each unit as follows: (1) Cut an oval or round shape vinyl patch, approximately 2" larger than the cut; (2) Clean around the torn area; (3) Apply glue on the patch and around the torn area; (4) Let it dry for 3 minutes; (5) Place the patch covering the damaged area and press with your palm for 1 minute. In approximately 15 minutes, the glue should dry and the unit will be ready to be inflated.

For larger tears, you can use the "Double Patch Method," as follows: (1) Put a patch inside the torn area by applying glue and pressing to the inside surface of the torn area; (2) After this is done, apply another patch to the outside surface of the torn area following the above-mentioned steps.

It is a good practice to clean the inflatables after each use. It is easier to clean the units in an inflated position by using dishwashing detergent and rags for general clean-up. To remove chewing gum, grease, adhesives, etc., use "**Goof Off**" and for mildew use "**X-14**." To reach high spots, untie the vent tube so unit gets soft and pull down from the sides.

WARNING: To clean printed areas of rides, never use any solvents or other type of cleaners except plain soap and water.

Make sure the unit is dry before rolling up and storing.

"**Lemon Pledge**" can be used for protection. All inflatables should be cleaned and dried every time they are exposed to rain to avoid mildew and unpleasant odors. If water has been accumulated inside the mattress and other inaccessible areas, the unit should be inflated outdoors and tilted to a 45 degree angle for as long as needed to drain all the water out.

A unit usually dries in about 2 hours.

ATTENTION: New Jersey Customers

All New Jersey based rental companies who purchased Ninja Jump inflatables are requested to refer to the Owner's Manual included with their purchase for procedures pertaining to the proper anchoring of the inflatables.

Per New Jersey Department of Community Affairs regulation, engineering certifications outline the appropriate anchor size and alternate ballast system taking into consideration live and wind loads.

Ninja Jump's standard package for Giant Slides does not include the ground anchors described in the Owners Manual but orders shipped starting Feb 1, 2007 will include 8 sand bags. The specified ground anchors are available and can be purchased separately from Hogan Company Inc. for New Jersey. Ask for steel stakes (5/8" diameter x 18"long) as mentioned in the Owners Manual. [AUGER-STYLE ANCHORS](#) (5/8" x 30"long or 18"long – if available) may also be used.


HOGAN COMPANY, INC
2741 South Lilac Ave
Bloomington, CA 92316

909 421-0245 phone
909 421-0249 fax

ORDER DESK: 800-214-6426
E-MAIL: carterhogancompany@earthlink.net
WEBSITE: www.stakesnotsteaks.com

* they also have warehouses in Nashville, TN and in Harrisburg, PA

DOUBLE LANE SLIDE TOP





Pre Operations Inspection Checklist

The following checklist is to be performed together in the presence of the Owner/Operator and the Renter upon each installation and set up of each inflatable ride and game manufactured by Ninja Jump, Inc. Failure to read, understand, and follow these rules could result in injury.

Date _____ Serial Number _____ NJI Game _____
 Renter Name _____ Driver/Attendant Name _____

Renter Initials	Owner/Rep. Initials	Inspected Areas	Comments/Action Taken
		Inflatable Game(s)	
		Weather conditions are safe for operation of all games	
		Vinyl/Patterns Clean and free of stains	
		Seams, and mesh are secure and in good condition	
		Tie down straps are strong with no breakage	
		Inflatable is staked in place, and will be anchored at all times	
		Inflatable is secured by sand bags, and will be anchored at all times	
		Entrance safety net is secure and in place	
		Entrance/Exits clear of obstructions and will remain clear	
		Entrance ramp is secure and attached	
		Warning signs are clear and visible	
		Internal air pressure is sufficient to give a firm footing	
		No debris or sharp objects are present	
		Passageways are clear of obstructions	
		Ropes and footholds are strong and intact	
		Slide area is controlled by overhanging cover	
		Inflatable is clear of any utility lines 20' above ground, laterally, and not exposed below ground	
		Accessories (If Applicable)	
		Blower is clean, and firmly attached to the inflatable	
		Blower is working and plugged into a GFCI 110v outlet	
		If using a generator, use all manufacturer's guidelines for operation	
		Electrical cords are free from wear and do not pose any trip hazards to patrons or guests	
		Misters are firmly attached and working	
		Water source is clean and free of debris and odor	
		Exiting water will drain away from the inflatable unit	
		Boxing gloves are clean inside and out	
		Jousting poles are clean, strong, and secure	
		Fencing is secure and in place	

I have inspected the inflatable unit(s) and find all items satisfactory and acceptable.

_____ Renter _____ Date _____



Operator/Attendant Responsibility Checklist

The following checklist is to be performed together in the presence of the Owner/Operator and the Renter upon each installation and set up of each inflatable ride and game manufactured by Ninja Jump, Inc. Failure to read, understand, and follow these rules could result in injury.

Date _____ Serial Number(s) _____
 NJI Game(s) _____
 Renter Name _____ Driver/Attendant Name _____

Renter Initials	Owner/Rep. Initials	<u>Operator/Attendant Responsibilities</u>	Comments/Action Taken
		*Supervision by an adult trained attendant is required at all times	
		The Operator/Attendant should point out and make all riders aware of the Rules posted on the side of the game.	
		The inflatable MUST BE securely anchored at all times	
		Entry into the inflatable device should be orderly and in a controlled manner	
		Riders should be of similar age range, height, and weight. Do not put older children or adults with younger children.	
		Individuals who may be particularly susceptible to injury from falls, bumps, or bouncing should not use this product. You should consult a physician before using this product	
		NO: Shoes, eyeglasses, jewelry, or other sharp objects	
		NO: Somersaults, diving, wrestling, rough play, or flips	
		NO: Food, drinks, gum, pets, or silly string	
		Do not jump onto or off of the ride.	
		Use of whistles and signaling devices is recommended	
		Keep patrons away from the blower at all times	
		DO NOT USE: and immediately deflate the inflatable if wind conditions exceed 15 mph and/or it rains	
		<u>For Rides with Climbs and Slides</u>	
		Go down the slide feet first only.	
		NO: climbing up the slide the wrong way	
		NO: jumping onto the slide area	
Renter Initials	Owner/Rep. Initials	<u>Emergency Procedures</u>	Comments/Action Taken
		<i>In the unlikely event of a severe Weather Alert, Power Failure, or a Medical Emergency:</i>	
		Exit patrons in an orderly fashion away from the game	
		Turn off the blower and unplug from the outlet	
		Keep patrons and guests away from the inflatable	
		Call the appropriate emergency responders if necessary	

I have been instructed in and understand the Operator/Attendant Responsibilities and the Emergency Procedures listed above.

_____ Renter Name _____ Date _____

_____ Owner/Rep. Name _____ Date _____



Scheduled Inspection and Maintenance Log

The following checklist is to be performed before each set up and operation of each inflatable ride and game manufactured by Ninja Jump, Inc., and as noted in the ASTM F-24 Standards on Amusement Rides and Devices. Failure to perform and document these inspections could result in injury and death, and non-compliance of state regulatory rules and regulations.

Ninja Jump Game:							
Serial Number:							
Name of person performing inspection:							
	MON	TUES	WED	THUR	FRI	SAT	SUN
Date	/ /	/ /	/ /	/ /	/ /	/ /	/ /
1. Inflatable Exterior							
• Vinyl Patterns clean and free of stains							
• Outside seams are strong and in good condition							
• Mesh is strong, stable and intact							
• *Proper stakes are being used for the intended soil composition							
• *Proper sand bags and weight are being used							
• Tie down straps are strong with no breakage							
• Entrance/Exits are clear of obstructions							
• Entrance Ramp is secure and attached							
• Warning signs and rules are clear and visible							
2. Inflatable Interior							
• Vinyl Patterns clean and free of stains							
• Inside seams are strong and in good condition							
• Mesh is strong, stable and intact							
• Entrance safety net is secure and intact							
• *Internal air pressure is sufficient to give a firm footing							
• No debris or sharp objects are present							
• Passageways are clear of obstructions							
• Ropes and footholds are strong and intact							
• Warning signs are clear and visible							
• Slide overhang cover is attached with no rips or tears							
* Refers to ASTM F-2374 Standards for Inflatable Amusement Rides							



Scheduled Inspection and Maintenance Log

The following checklist is to be performed before each set up and operation of each inflatable ride and game manufactured by Ninja Jump, Inc., and as noted in the ASTM F-24 Standards on Amusement Rides and Devices. Failure to perform and document these inspections could result in injury and death, and non- compliance of state regulatory rules and regulations.

Ninja Jump Game:								
Serial Number:								
Name of person performing inspection:								
	MON	TUES	WED	THUR	FRI	SAT	SUN	
Date	/ /	/ /	/ /	/ /	/ /	/ /	/ /	/ /
3. Blowers								
• *Proper blower is being used for this unit								
• *Intended electrical outlet is a (GFCI) 110v outlet								
• Motor is free of dust and is working								
• Air intake and output are clean and free of debris								
• Blower is free of rust								
• Inflatable air tube and blower hose are securely attached								
• Electrical cords are not more than 25' from the GFCI outlet								
• Electrical cords are encased and free from wear								
• Electrical cords are secure and do not pose a trip hazard								
• Plugs sockets, and switches are not damaged								
4. Accessories (if applicable)								
• Wind Anemometer is working								
• Misters are firmly attached and free of debris and odor								
• Water source is clean and free of debris								
• Surrounding water run off area will drain and not pool								
• Boxing gloves are clean inside and out								
• Jousting poles are clean, strong, and secure								
• *All fencing queues and railings are intact, free from sharp edges and obstructions								
• If using a generator, use all manufacturer's guidelines for operation								
* Refers to ASTM F-2374 Standards for Inflatable Amusement Rides								

